



AIRCCLASSICS®

Headset Head Pad

HS-1-PAD

Assembly Instructions:

The Headset Head Pad is designed to fit spring steel headbands up to 5/8" wide. It may be modified to fit headbands slightly larger.

Disassemble headband locknut assembly (A), and slide existing rubber head pad stiffener off the spring steel headband (B). (Some head pads may need to be cut off of the headband with sharp scissors or a razor blade.) Most headbands have several pieces of friction-reducing material sandwiched between the headband pieces (C). Be careful not to damage or misplace this material to ensure proper operation.

Slide the new, rubber head pad stiffener (included) onto the headband until it is positioned in the center of the headband (D). Slide crossover cable into channel on stiffener (E).

Attach microfiber fleece head pad by folding flaps over stiffener and attaching hook and loop fastener (F).

